# Installation Guide

2.4-inch Series Product

Version: 1.0

#### Installation Environment

Please refer to the following recommendations for installation.



KEEP DISTANCE



AVOID GLASS REFRACTION




AVOID DIRECT SUNLIGHT AND EXPOSURE



AVOID USE OF ANY HEAT SOURCE NEAR THE DEVICE

### **Device Installation**

- Stick the mounting template sticker to the wall and drill holes according to the mounting template sticker.
- (2) Fix the backplate on the wall using wall mounting screws
- (3) Attach the device to the backplate
- 4 Attach the device to the backplate with a security screw.










#### **Power Connection**




#### **Recommended AC Adapter**

- 1)  $12V \pm 10\%$ , at least 1500mA.
- To share the power with other devices, use an AC Adapter with higher current ratings.

#### **Ethernet Connection**


Connect the device and computer software via an Ethernet cable. As shown in the example below:



Enter [COMM.] > [Ethernet] > [IP Address], input the IP address and press M/OK.


**Note:** In LAN, the IP address of the server (PC) and the device must be in the same network segment when connecting to the software.

#### **Door Sensor & Exit Button Connection**



## **Lock Relay Connection**

The system supports Normally Opened Lock and Normally Closed Lock. The NO LOCK (normally unlocks when power-on) is connected with 'NO' and 'COM' terminals, and the NC LOCK (normally locks when power-on) is connected with 'NC' and 'COM' terminals. Take NC Lock as an example below:



## **Download Center**

Scan the QR Code to download the **User Manual**, **Installation Guide** and **Quick Start Guide**.



QR Code (Download Center)

